

Maintenance recommendations after use (every time)

Wear full protective gear during maintenance!

Always act according to the safety instructions as supplied with each tool!

- For all thermoplastic Core hose assemblies
- Necessary equipment: soft cloth

! Replace the Core hose if one of the following items is wrong.



Step 1

- Check general condition Core hose.
- Check Core hose for traces of oil leakage.
- Clean the Core hose with water and soap when it has been in contact with aggressive fluids.



Step 2

- Check Core couplers and dust caps for dirt and/or oil leakage.
- Clean Core couplers with a clean and soft cloth, if necessary with water and soap.
- If necessary grease with hydraulic oil or use WD-40.
- Check functioning Core couplers (see fig. 1, page 4).
- Reconnect loose dust caps to Core couplers.



Step 3

 Replace the Core hose, when obvious traces of kinks are visible.



Step 4

 Replace the Core hose when damage is such that the one braided layer of high tensile synthetic fibre is clearly visible.



Step 5

Replace the Core hose, when blisters are visible.



Step 6

 Replace the Core hose, when bubbles or bulges higher than 1mm are visible.

Manufacturing sales & service worldwide

Holmatro Rescue Equipment

P.O. Box 33, 4940 AA Raamsdonksveer The Netherlands

T + 31 (0)162 - 58 92 00

F + 31 (0)162 - 52 24 82

E info@holmatro.com www.holmatro.com

Manufacturing sales & service U.S.A., Canada and Latin America

Holmatro, Inc.

505 McCormick Drive, Glen Burnie, MD 21061 U.S.A

T + 1 - 410 - 768 - 9662

F + 1 - 410 - 768 - 4878

E info@holmatro-usa.com www.holmatro-usa.com

© Holmatro®

06-12

While the greatest care has been devoted to the content, it is possible that the information in this printed matter is incorrect or incomplete. Holmatro NV. and its affiliated companies (hereafter: Holmatro) cannot be held liable in any way for the consequences of activities undertaken on the basis of this printed matter. If you have any doubts about the correctness or completeness of the information, you shall contact Holmatro (phone number: +31 (0)162-585200).

Nothing from this printed matter can be copied and/or made public in any way without the explicit authorisation of Holmatro.