



# THREE STRUT COLUMN

	6x	<b>Swivel Base</b>
	2x	<b>Column Clamp</b>



### Notes

- The shoring construction/installation must always be approved by a trained Structural Specialist.
- The capacity of a Three Strut Column is 3x the load as shown in the Working Load Chart (see below).
- Always use 2 Column Clamps.
- Place the Column Clamps on approx. 1/3 and 2/3 of the Total Height.

